

INSPECTION

Disconnect the ECM 21P (Gray) connector (page 4-28).

Check for continuity between the following terminals of the ECM 21P (Gray) connector [1] of the wire harness side.

TOOL:

Test probe, 2 pack

07ZAJ-RDJA110

CONNECTION: Green/white – Blue/green

There should be continuity with the sidestand retracted, and there should be no continuity with the sidestand applied.

If there is no continuity with the sidestand retracted, the wire harness is broken or the sidestand switch is faulty.

